



- Nanoengineered textile disinfectant
- Biocompatible and non-toxic
- Lab tested and certified
- Bactericidal effect is maintained up to 15 days



DIRECTIONS FOR USE



1. Homogenize NanOhWash solution before use.



2. Machine wash: add 65mL of NanOh Wash in the softener compartment (together with the fabric softener) to treat 4/5kg of laundry.



3. Hand wash: add 30mL of NanOh Wash in 25L of water for 10 minutes (minimum time).

FIELDS OF APPLICATION

Performant textile disinfectant, for use in the washing machine or hand wash. NanOh Wash, through the use of Sil2U® technology, provides an excellent bactericidal activity against Gram-positive and Gram-negative Bacteria, as well as Fungi.

PERFORMANCE SPECTRUM

The bactericidal effect is maintained up to 15 days over textiles on Klebsiella pneumoniae and Staphylococcus aureus, with 99,9% of efficacy.

SPECIAL PROPERTIES

NanOh Wash is a textile finishing product based on the dispersion of silica particles loaded with an antibacterial agent. The active substance within Sil2U® technology is an effective antibacterial agent and is approved by the World Health Organization (WHO) for the prevention of hospital-acquired infections.

APPLICATION AND DOSAGE

Homogenize NanOh Wash before use. Machine wash : add 65mL of NanOh Wash in the softener compartment (together with the fabric softener) to treat 4/5 kg of laundry.

Hand wash: add 30mL of NanOh Wash in 25L of water. Soak for minimum 10 minutes.

NOTE ON APPLICATION

Avoid contact with eyes, mouth, mucous membranes, and irritated skin. In case of contact with eyes, rinse immediately with plenty of running water. Do not ingest or use with other products. Keep out of reach of children.

STORAGE INFORMATION

Store in a cool, well-ventilated area, not exposed to sunlight. Dispose of contents/container in accordance with local regulations.

TECHNICAL DATA

pH range	4-5 at 20 °C
Density	1.00 g cm ⁻³ at 20 °C
Aspect	Turbid
Odor	Characteristic

PACKAGING

Unit size	Unit of Sale	Product order codes
3 liter bottle	4 x 3 liters	NS - 3L

Larger sizes available upon request

For further information
please contact us:
+ 41 79 469 42 48
+ 41 22 747 10 00
franck@nanohtech.com

